



| an EnerSys company

# **Cordex HP 2.4kW / 3.0kW Switched Mode Rectifier System**

**Models:**

**Cordex® HP CXRF 48-3.0kW**

**Cordex® HP CXRF 48-2.4kW**

**User Guide ID: 0100037-J0**

**Effective: 05/2021**



**Read this manual carefully.**

Learn how to protect your equipment from damage and fully understand its functions.

## **Cordex® HP 3.0kW switched mode rectifier system**

Shelf models: 19 inch 1RU universal mount 12,000W  
23 inch 1RU universal mount 15,000W

## **Cordex® HP 2.4kW switched mode rectifier system**

Shelf models: 19 inch 1RU universal mount 9,600/12,000W  
23 inch 1RU universal mount 12,000/15,000W

### **NOTE**

---

Photographs contained in this manual are for illustrative purposes only. These photographs may not match your installation.

### **NOTE**

---

Operator is cautioned to review the drawings and illustrations contained in this manual before proceeding. If there are questions regarding the safe operation of this powering system, contact Alpha Technologies or your nearest Alpha representative.

### **NOTE**

---

Alpha shall not be held liable for any damage or injury involving its enclosures, power supplies, generators, batteries, or other hardware if used or operated in any manner or subject to any condition inconsistent with its intended purpose, or if installed or operated in an unapproved manner, or improperly maintained.

## **For technical support, contact Alpha Technologies:**

Canada and US: 1.888.462.7487

International: +1.604.436.5547

Email: [support@alpha.ca](mailto:support@alpha.ca)

## **Copyright**

Copyright © 2021 Alpha Technologies Ltd. All rights reserved. Alpha is a registered trademark of Alpha Technologies.

No part of this documentation shall be reproduced, stored in a retrieval system, translated, transcribed, or transmitted in any form or by any means manual, electric, electronic, electromechanical, chemical, optical, or otherwise without prior explicit written permission from Alpha Technologies.

This document, the software it describes, and the information and know-how they contain constitute the proprietary, confidential and valuable trade secret information of Alpha Technologies, and may not be used for any unauthorized purpose, or disclosed to others without the prior written permission of Alpha Technologies.

The material contained in this document is for information only and is subject to change without notice. While reasonable efforts have been made in the preparation of this document to assure its accuracy, Alpha Technologies assumes no liability resulting from errors or omissions in this document, or from the use of the information contained herein. Alpha Technologies reserves the right to make changes in the product design without reservation and without notification to its users.

# Contents

- 1. Safety ..... 4
  - 1.1 Safety symbols ..... 4
  - 1.2 General safety ..... 4
  - 1.3 Mechanical safety ..... 5
  - 1.4 Electrical safety ..... 5
  - 1.5 Battery safety ..... 5
- 2. Introduction ..... 6
  - 2.1 Scope of the manual ..... 6
  - 2.2 Product overview ..... 6
  - 2.3 Part numbers ..... 7
- 3. Specifications ..... 8
  - 3.1 Cordex HP 3.0kW rectifier ..... 8
  - 3.2 Cordex HP 2.4kW rectifier ..... 11
- 4. Features ..... 13
  - 4.1 Cordex HP 3.0kW rectifier ..... 13
  - 4.2 Cordex HP 2.4kW rectifier ..... 18
- 5. Inspection ..... 22
  - 5.1 Packing materials ..... 22
  - 5.2 Check for damage ..... 22
  - 5.3 General receipt of shipment ..... 22
- 6. Installation ..... 23
  - 6.1 Installation overview ..... 23
  - 6.2 Safety precautions ..... 23
  - 6.3 Installation tools ..... 23
  - 6.4 Assembly and mounting ..... 24
  - 6.5 DC output connections - bulk distribution ..... 25
  - 6.6 AC wiring 23 inch shelf ..... 28
  - 6.7 AC wiring 19 inch shelf ..... 29
  - 6.8 Communication cabling (optional) ..... 30

6.9	System startup .....	33
<b>7.</b>	<b>Wiring.....</b>	<b>34</b>
7.1	Installation notes .....	34
7.2	Calculating output wire size requirements .....	34
7.3	Grounding .....	35
<b>8.</b>	<b>Rectifier modes and factory defaults.....</b>	<b>36</b>
8.1	Rectifier modes .....	36
8.2	Factory ranges and defaults .....	37
<b>9.</b>	<b>Maintenance .....</b>	<b>38</b>
9.1	Replacing a rectifier module via the Cordex HP controller .....	38
9.2	Replacing a rectifier module via Cordex controller .....	39
9.3	Fan replacement.....	39
<b>10.</b>	<b>Troubleshooting .....</b>	<b>41</b>
<b>11.</b>	<b>Acronyms and definitions .....</b>	<b>42</b>
<b>12.</b>	<b>Warranty statement and service information .....</b>	<b>43</b>
12.1	Technical support .....	43
12.2	Warranty statement.....	43
12.3	Product warranty .....	43
12.4	Battery warranty .....	43
12.5	Warranty claims .....	43
12.6	Service information .....	43
<b>13.</b>	<b>Certification .....</b>	<b>44</b>

# 1. Safety

---


## Save these instructions


This manual contains important safety instructions that must be followed during the installation, servicing, and maintenance of the product. Keep it in a safe place. Review the drawings and illustrations contained in this manual before proceeding. If there are any questions regarding the safe installation or operation of this product, contact Alpha Technologies or the nearest Alpha representative. Save this document for future reference.

### 1.1 Safety symbols

To reduce the risk of injury or death, and to ensure the continued safe operation of this product, the following symbols have been placed throughout this manual. Where these symbols appear, use extra care and attention.

The use of ATTENTION indicates specific regulatory/code requirements that may affect the placement of equipment or installation procedures.


 **NOTE**  
A NOTE provides additional information to help complete a specific task or procedure. Notes are designated with a check mark, the word NOTE, and a rule beneath which the information appears.

 **CAUTION!**  
CAUTION indicates safety information intended to PREVENT DAMAGE to material or equipment. Cautions are designated with a yellow warning triangle, the word CAUTION, and a rule beneath which the information appears.

 **WARNING!**  
WARNING presents safety information to PREVENT INJURY OR DEATH to personnel. Warnings are indicated by a shock hazard icon, the word WARNING, and a rule beneath which the information appears.

 **HOT!**  
The use of HOT presents safety information to PREVENT BURNS to the technician or user.

### 1.2 General safety

 **WARNING!**  
This system is designed to be installed in a restricted access location that is inaccessible to the general public.

Ce système est conçu pour être installé dans un endroit à accès restreint inaccessible au grand public.

 **WARNING!**  
This equipment is not suitable for use in locations where children are likely to be present.

Cet équipement ne convient pas pour une utilisation dans des lieux où des enfants sont susceptibles d'être présents.

## 1.3 Mechanical safety

- Keep hands and tools clear of fans. Fans are thermostatically controlled and switch on automatically.
- Power supplies can reach extreme temperatures under load.
- Use caution around sheet metal components and sharp edges.

## 1.4 Electrical safety



### WARNING!

**Hazardous voltages are present at the input of power systems. The DC output from rectifiers and batteries, though not dangerous in voltage, has a high short-circuit current capacity that may cause severe burns and electrical arcing.**

Before working with any live battery or power system, follow these precautions:

- Remove all metallic jewelry, such as watches, rings, metal rimmed glasses, or necklaces.
- Wear safety glasses with side shields at all times during the installation.
- Use OSHA (or international equivalent) approved insulated hand tools.



### WARNING!

**Lethal voltages are present within the power system. Always assume that an electrical connection or conductor is energized. Check the circuit with a voltmeter with respect to the grounded portion of the enclosure (both AC and DC) before performing any installation or removal procedure.**

- Do not work alone under hazardous conditions.
- A licensed electrician is required to install permanently wired equipment. Input voltages can range up to 277Vac nominal. Ensure that the utility power is disconnected and locked out before performing any installation or removal procedure.
- Ensure that no liquids or wet clothes come into contact with internal components.
- Hazardous electrically live parts inside this unit are energized from the batteries even when the AC input power is disconnected.

## 1.5 Battery safety

- Servicing and connection of batteries must be performed by, or under the direct supervision of, personnel knowledgeable of batteries and the required safety precautions.
- Always wear eye protection, rubber gloves, and a protective vest when working near batteries. Remove all metallic objects from your hands and neck.
- Use OSHA (or international equivalent) approved insulated hand tools. Do not rest tools on top of batteries.
- Batteries contain or emit chemicals known to cause cancer and birth defects or other reproductive harm. Battery post terminals and related accessories contain lead and lead compounds. Wash your hands after handling batteries.



### WARNING!

**Follow battery manufacturer's safety recommendations when working around battery systems. Do not smoke or introduce an open flame when batteries (especially vented batteries) are charging. When charging, batteries vent hydrogen gas, which can explode.**

Batteries are hazardous to the environment and should be disposed at a recycling facility. Consult the battery manufacturer for recommended local authorized recyclers.

## 2. Introduction

---

### 2.1 Scope of the manual

This manual explains the installation, interconnection, and operation of:

- Cordex HP 3.0kW rectifier systems
- Cordex HP 2.4kW rectifier systems.

### 2.2 Product overview

A complete rectifier system consists of one or more power modules in a common shelf enclosure. The shelf has connections for AC inputs, DC output, and system communications. The wide AC input operating range for global installations and wide operating temperature ranges for installation in uncontrolled environments along with high efficiency (>96%) reduces the carbon footprint and the operating expenses.

Cordex rectifier modules use a high frequency, switched mode conversion technique to provide a fully regulated and isolated DC output from the AC mains. Multiple 48V configurations are available up to 312.5A in a compact 1RU shelf system. Industry leading power density (35W/in<sup>3</sup>) yields more space for revenue generating equipment.

Rectifier power modules are “hot swappable”—they can be inserted or removed from the shelf without cutting power to or from the system or the load. Additional power modules can be included with the system at the time of ordering or added after the shelf has been installed.

The shelf rectifier system is designed to operate with the Cordex System Controller (CXC). This controller allows the user to configure, monitor, and control the entire DC power system from its touch screen display which includes temperature compensation, auto equalization, remote access, dial out on alarm, battery diagnostics, as well as Web server and SNMP support for configuration and monitoring. Details of controller operation are provided in the current version of the related software manual.

External system controller models communicate with the shelf via RJ12 shelf connectors. In a power system, up to five rectifier shelves can be stacked and connected to the same controller. The latest Cordex HP controller, featuring touch screen, color LCD display with front Ethernet and USB connectors, is available as a panel mount controller or as part of the CXPS-E3 system.

Shelf ID location technology is built into the **Cordex HP 3.0kW rectifier**. This feature is capable of remotely locating the exact position of a rectifier within a large system. This can be useful for quickly locating a unit during a service interruption or when a unit has failed.



Figure 1 — Cordex HP 19 inch rectifier shelf

## 2.3 Part numbers

The product, options, and accessories can be ordered by using the part numbers in the following tables.

### 2.3.1 Cordex HP 3.0kW rectifier

Description	Part numbers
23 inch 1RU universal mount 15000W shelf* <ul style="list-style-type: none"> <li>• bulk power for external distribution</li> <li>• up to five Cordex HP 3.0kW rectifiers</li> </ul>	0300216-001 (shelf/slot ID supported)
19 inch 1RU universal mount 12000W shelf* <ul style="list-style-type: none"> <li>• bulk power for external distribution</li> <li>• up to four Cordex HP 3.0kW rectifiers</li> </ul>	0300228-001 (shelf/slot ID supported)
Cordex HP 3.0kW rectifier	0100037-001
Fan assembly replacement	7400732-001
Module blank	7400424-001
Rear DC output 19 inch shelf cover	0370250-001
Rear DC output 23 inch shelf cover	0370250-002
*Note: Standard DC busbars available up to a maximum of five shelves per system.	

### 2.3.2 Cordex HP 2.4kW rectifier

Description	Part number
23 inch 1RU universal mount 12000/15000W shelf* <ul style="list-style-type: none"> <li>• bulk power for external distribution</li> <li>• up to five Cordex HP 2.4kW   3.0kW rectifiers</li> </ul>	0300057-001
19 inch 1RU universal mount 9600/12000W shelf* <ul style="list-style-type: none"> <li>• bulk power for external distribution</li> <li>• up to four Cordex HP 2.4kW   3.0kW rectifiers</li> </ul>	0300040-001
19 inch 1RU universal mount, 4 × 2.4kW/3.0kW outputs <ul style="list-style-type: none"> <li>• individual rectifier outputs</li> <li>• up to four Cordex HP 2.4kW   3.0kW rectifiers</li> </ul>	0300040-002
Cordex HP 2.4kW rectifier	0100003-001
Fan assembly replacement	7400374-001
Module blank	7400424-001
Rear DC output 19 inch shelf cover	0370250-001
Rear DC output 23 inch shelf cover	0370250-002
*Note: Standard DC busbars available up to a maximum of five shelves per system.	



## 3. Specifications

### 3.1 Cordex HP 3.0kW rectifier

<b>Table A — Cordex 3.0kW rectifier specifications</b>	
<b>Electrical</b>	
<b>Input specifications</b>	
<b>Nominal input</b>	208 to 277Vac
<b>Full power</b>	187 to 300Vac
<b>Input operational</b>	90 to 300Vac
<b>Input extended high</b>	277 to 300Vac reduced input PF
<b>Input extended low</b>	90 to 187Vac derate linearly to 1200W
<b>Input frequency</b>	45 to 65Hz
<b>Input nominal</b>	15.5A at 208 to 277Vac
<b>Input maximum</b>	16.5A at 185Vac
<b>Power factor</b>	>98% at nominal input 50% to 100% load
<b>Inrush current</b>	≤ full load steady state current of the rectifier within rated limits
<b>Start-up ready times</b>	<5 seconds
<b>Start-up delay</b>	Programmable up to 120 seconds
<b>Soft start</b>	User adjustable to at least 5 seconds
<b>Protection</b>	10kA interrupting in L and N wires
<b>THD current</b>	<5% at nominal input 100% load
<b>Input leakage current</b>	<3.5mA at 265Vac with 2 rectifiers
<b>Output specifications</b>	
<b>Output voltage</b>	42 to 58Vdc
<b>Maximum power</b>	3000W
<b>Output current</b>	55.5A at 54Vdc
<b>Maximum output current</b>	62.5A at 48Vdc
<b>Holdup time</b>	>5ms at 100% Load
<b>Characteristics</b>	
<b>Efficiency</b>	>96.2% peak 95% at nominal input 50 to 100% load
<b>Acoustic noise</b>	<55dBa at 1m (3ft) 30°C (86°F)
<b>Static load regulation</b>	≤ ±0.5% for any load change within full load limits
<b>Dynamic load regulation (40%-90%, 90%-40%)</b>	≤ ±3.0% for any load change within rated limits
<b>Static line regulation</b>	≤ 0.1% for any change in input voltage within full load limits
<b>Temperature stability</b>	≤100ppm/°C over operating temperature
<b>Time stability</b>	≤ 0.2% per year
<b>Electrical noise (nominal voltages)</b>	
<b>Voice band</b>	<53dBnc
<b>Wide band 10kHz to 10MHz</b>	<260mVrms

<b>Wide band 10kHz to 100MHz</b>	<180mVpk-pk
<b>Reliability</b>	
<b>MTBF</b>	623,860 hours Telcordia SR-332 Issue 3 Method 1 Case 3, Parts Count Method, Quality Level II Ambient temperature 30°C, Environment: Ground Fixed, Controlled, 100% Duty Cycle, Full Load  (Remarks) <ul style="list-style-type: none"> <li>• Devices are assumed to be operating at ambient temperature and 50% rated electrical stress. However, the operating point and temperature of selected critical components was measured and included in the model for improved accuracy.</li> <li>• All components are assumed to be necessary for operation of the product.</li> <li>• Failures are expected to have an exponential distribution during the useful life period of the product.</li> <li>• The MTBF calculation does not include batteries, software, or mechanical parts.</li> </ul>
<b>Mechanical</b>	
<b>Dimensions H × W × D</b>	41mm × 104mm × 333mm (1.6in × 4.1in × 13.1in)
<b>Weight</b>	1.76 kg (3.9 lbs)
<b>Environmental</b>	
<b>Temperature</b>	
<b>Operating full power</b>	−40°C to 55°C (−40°F to 131°F)
<b>Extended</b>	55°C to 75°C (131°F to 167°F) derate to 600W
<b>Storage</b>	−40°C to 85°C (−40°F to 185°F)
<b>Characteristics</b>	
<b>Relative humidity</b>	0 to 95% (non-condensing)
<b>Heat dissipation</b>	<500 BTU per hour (146.5W) (worst case: 100% load at 187 Vac)
<b>Elevation</b>	−500m to 3000m (−1640ft to 9842ft)

### 3.1.1 Cordex 48-3.0kW rectifier shelves

<b>23 inch 1RU universal mount 15,000W shelf P/N 0300216-001 (shelf/slot ID supported)</b>	
<b>Number of rectifiers</b>	Five Cordex HP 48-3.0kW rectifiers
<b>Nominal AC input current (two modules per feed)</b>	120Vac; 29A (per feed); 50/60Hz 208 to 277Vac; 31-24A (per feed); 50/60Hz
<b>Recommended input feeder breakers (three feeds per shelf)</b>	40A per feed for rectifier pairs with nominal 120, 208, 240, 277 Vac 20A per feed for individual rectifier with nominal 120, 208, 240, 277 Vac
<b>Recommended AC input wire size</b>	40A: 8 AWG line; 10 AWG protective earth 20A: 12 AWG line; 14 AWG protective earth
<b>Shelf output power</b>	15kW maximum
<b>Distribution</b>	Bulk power for external distribution
<b>Dimensions H × W × D</b>	44mm × 537mm × 420mm (1.75in × 21.1in × 16.5in)
<b>Weight</b>	5.7kg (12.6lbs)

<b>Communications ports</b>	CAN: interface to control rectifiers and smart peripherals
	Shelf ID: interface to connect to bay ID module
<b>19 inch 1RU universal mount 12,000W shelf P/N 0300228-001 (shelf/slot ID supported)</b>	
<b>Number of rectifiers</b>	Four Cordex HP 48-3.0kW rectifiers
<b>Nominal AC input current (one module per feed)</b>	120Vac; 14.2A (per feed); 50/60Hz 208 to 277Vac; 15.5 to 12A (per feed); 50/60Hz
<b>Recommended input feeder breakers (four feeds for shelf)</b>	20A per feed for nominal 120, 208, 240, 277 Vac
<b>Recommended AC input wire size</b>	12 AWG line; 14 AWG protective earth
<b>Shelf output power</b>	12kW maximum
<b>Distribution</b>	Bulk power for external distribution
<b>Dimensions H × W × D</b>	44mm × 438mm × 420mm (1.75in × 17.3in × 16.5in)
<b>Weight</b>	4.5kg (9.9lbs)
<b>Communications ports</b>	CAN: interface to control rectifiers and smart peripherals
	Shelf ID: interface to connect to bay ID module
<b>Compliance</b>	
<b>Safety</b>	CSA C22.2 No 60950-1-07 + Am.1:2011 +Am.2:2014 UL 60950-1-2014 IEC/EN 60950-1:2006 +A11:2009 +A1:2010 +A12:2011 +A2:2013 CAN/CSA-C22.2 No. 62368-1:14 ANSI/UL 62368-1 2nd Ed IEC 62368-1:2014 (Second Edition) EN 62368-1:2014+A11:2017
<b>EMC</b>	FCC Section 15B / ICES 003 Class A Digital Device IEC/EN 55024:2010 ITE Equipment - Immunity Characteristics IEC/EN 55032/CISPR 32 Class A:2012 +AC:2013 IEC/EN 61000-3-2:2014 Harmonic Current Emission IEC/EN 61000-3-3:2013 Voltage Fluctuations and Flicker IEC/EN 61000-4-2:2008 ESD Immunity IEC/EN 61000-4-3:2006 +A1:2007 +A2:2010 Radiated Electromagnetic Immunity IEC/EN 61000-4-4:2012 Electrical Fast Transient/Burst Immunity IEC/EC 61000-4-5:2014 +A1:2017 Surge Immunity Test IEC/EN 61000-4-6:2013 Immunity to Conducted Disturbances IEC/EN 61000-4-8:2009 Power Frequency Magnetic Field IEC/EN 61000-4-11:2004 +A1:2017 Voltage Dips & Interruptions IEC/EN 61000-6-4:2007 +A1:2011 Generic Standards Industrial Environment
<b>Directives</b>	2014/35/EU Low Voltage Directive (LVD) 2014/30/EU EMC Directive 2011/65/EU Restriction on use of Hazardous Substances (RoHS2/6) Category of EEE (Annex 1): Category 3 IT and Telecommunications Equipment Category of EEE (Annex 1): Category 11 Other Electrical and Electronic Equipment

## 3.2 Cordex HP 2.4kW rectifier

<b>Table B — Cordex 2.4kW rectifier specifications</b>	
<b>Electrical</b>	
<b>Input voltage</b>	
<b>Nominal</b>	208 to 277Vac
<b>Operating</b>	90 to 310Vac
<b>Extended</b>	90 to 187Vac (de-rated power)
<b>Input frequency</b>	44 to 66Hz
<b>Power</b>	2400W continuous (1200W output at 120Vac Input)
<b>Power factor</b>	>0.99 (50 to 100% load)
<b>THD</b>	<5%
<b>Efficiency</b>	96.2% peak
<b>Output voltage</b>	42 to 58Vdc (No load 46.5 to 58Vdc)
<b>Output current</b>	44.5A at 54Vdc (50A max at 48Vdc) (~25A at 48Vdc at 120Vac input)
<b>Load regulation</b>	<±0.7% (static)
<b>Line regulation</b>	<±0.1% (static)
<b>Transient response</b>	±3% for 40 to 90% load step
<b>Noise</b>	
<b>Voice band</b>	<38dBnC
<b>Wide band</b>	<20mV RMS (10kHz to 10MHz) <150mV peak to peak (10kHz to 100MHz)
<b>Psophometric noise</b>	<2mV RMS
<b>Acoustic</b>	<60dBa at 1m (3ft), 30°C
<b>Reliability</b>	
<b>MTBF</b>	627,000 hours per Telcordia SR-332 Issue 3 (2011)
<b>Mechanical</b>	
<b>Dimensions H × W × D</b>	41mm × 104mm × 333mm (1.6in × 4.1in × 13.1in)
<b>Weight</b>	1.76kg (3.9lbs)
<b>Environmental</b>	
<b>Temperature</b>	
<b>Operation</b>	−40°C to 75°C (−40°F to 149°F)
<b>Full nominal output power</b>	−40°C to 55°C (−40°F to 131°F); >2000W at 65°C (167°F)
<b>Storage</b>	−40°C to 85°C (−40°F to 185°F)
<b>Operating humidity</b>	0 to 95% (non-condensing)
<b>Heat dissipation</b>	<350 BTU per hour (102.6W) (typical) <500 BTU per hour (146.5W) (worst case: 100% load at 187Vac)

### 3.2.1 Cordex 48-2.4kW rectifier shelves




23 inch 1RU universal mount 12,000/15,000W shelf P/N 0300057-001	
<b>Number of rectifiers</b>	Five Cordex HP 48-2.4kW/3.0kW rectifiers
<b>Nominal AC input current (two modules per feed)</b>	120Vac; 23A (per feed); 50/60Hz 208 to 277Vac; 25 to 19A (per feed); 50/60Hz
<b>Recommended input feeder breakers (three feeds per shelf)</b>	40A per feed for rectifier pairs with nominal 120, 208, 240, 277 Vac 20A per feed for individual rectifier with nominal 120, 208, 240, 277 Vac
<b>Recommended AC input wire size</b>	40A: 8 AWG line; 10 AWG protective earth 20A: 12 AWG line; 14 AWG protective earth
<b>Shelf output power</b>	15kW maximum
<b>Distribution</b>	Bulk power for external distribution
<b>Dimensions H × W × D</b>	44mm × 537mm × 420mm (1.75in × 21.1in × 16.5in)
<b>Weight</b>	5.7kg (12.6lbs)
<b>Communications ports</b>	CAN: interface to control rectifiers and smart peripherals
19 inch 1RU universal mount 9,600/12,000W shelf P/N 0300040-001/002	
<b>Number of rectifiers</b>	Four Cordex HP 48-2.4kW/3.0kW rectifiers
<b>Nominal AC input current (one module per feed)</b>	120Vac; 11.5A (per feed); 50/60Hz 208 to 277Vac; 12.5 to 9.5A (per feed); 50/60Hz
<b>Recommended input feeder breakers (four feeds for shelf)</b>	20A per feed for nominal 120, 208, 240, 277 Vac
<b>Recommended AC input wire size</b>	12 AWG line; 14 AWG protective earth
<b>Shelf output power</b>	12kW maximum
<b>Distribution options</b>	Bulk power for external distribution (0300040-001) Separate feed IO (0300040-002)
<b>Dimensions H × W × D</b>	44mm × 438mm × 420mm (1.75in × 17.3in × 16.5in)
<b>Weight</b>	4.5kg (9.9lbs)
<b>Communications ports</b>	CAN: interface to control rectifiers and smart peripherals
Compliance	
<b>Safety</b>	CSA C22.2 No 60950-1-07 + Am.1:2011 +Am.2:201 UL 60950-1-2014 IEC/EN 60950-1:2006 +A11:2009 +A1:2010 +A12:2011
<b>EMC</b>	FCC Section 15B / ICES 003 Class A Digital Device IEC/EN 55022:2010 ITE Equipment - Immunity Characteristics IEC/EN 61000-3-2:2006 Harmonic Current Emissions IEC/EN 61000-4-4:2012 Electrical Fast Transient/Burst Immunity IEC/EN 61000-4-6:2009 Immunity to Conducted Disturbances

## 4. Features

### 4.1 Cordex HP 3.0kW rectifier

#### 4.1.1 Front panel LEDs

The front panel LEDs indicate the rectifier status summary and patterned response to **Locate Module** command.

	<b>Alarm/Fault</b>	<p>The red LED is on during an active Module Fail alarm if the module is unable to source power due to a fault condition. Refer to the relevant controller manual for fault details.</p> <p>The LED flashes (~2Hz) when a minor alarm is detected if the module's output capability has been reduced or a minor failure is detected.</p> <p>The red LED will remain active if the module is receiving power from the DC bus.</p>
	<b>DC ON</b>	<p>The green LED is on when the rectifier is delivering power to the load. The LED goes out when the rectifier is off. For example, when commanded by the controller.</p>
	<b>AC ON</b>	<p>The green LED is on when the AC input voltage is qualified and within the operational AC input range and input frequency.</p>

#### LED activity during the Locate Module command from controller

The **Locate Module** command from the Cordex HP controller, causes the LEDs of the target rectifier to flash in a cyclical pattern. This flashing lasts approximately 60 seconds.

#### LED activity during power save

When a rectifier is put into power save mode, only the AC ON LED remains illuminated.

#### 4.1.2 True module fail alarm

The power modules have a “true” fail alarm that provides a true indication of the power module’s ability to source current. When the module’s output current drops below 2.5 percent of the rated output, a low output current condition is detected and the **Module Fail detection circuit** is activated. This circuit momentarily ramps up the output voltage to determine if the module will source current. If no increase in current is detected, the **Module Fail** alarm is activated. The module will test once every 60 seconds for the condition until a current is detected. The output voltage ramping ceases upon detection of current. A minimum 2.5 percent load is required to avoid the **Ramp Test Fail** alarm. This load can be provided with the parallel system battery. Activation of this alarm could indicate a failed module or a failed load.


To avoid nuisance alarms for Cordex rectifier systems without batteries, or with a very light load (below 2.5 percent of the rated output), the ramp test should be disabled. Disable the Ramp Test via the Cordex HP controller menu: **System > DC System > Inventory > Rectifiers > Configuration**.

#### 4.1.3 Heat dissipation

Each rectifier module is equipped with a front-mounted, variable-speed fan. The fan speed is determined based on ambient temperature, rectifier temperature, and the load. Air flow is front-to-rear with the exhaust air exiting through internal vents at the rear of the unit. The fan may spin in required situations.


### 4.1.4 Over temperature protection

Blockage or obstruction to the air flow can result in the internal temperature to rise and reduce the output power or even shut down the rectifier. The rectifier will resume normal operation when the temperature reduces to a safe level. Over temperature shut down can also occur when a fan failure has occurred. The rectifier; to protect itself from ambient over temperature scenarios; will limit its output power.



### 4.1.5 AC input power derating

The 3.0kW rectifier power varies with different input voltages. This is to reduce the chance of having an AC input breaker trip from drawing the same amount of power at lower input voltages.



### 4.1.6 AC inrush/transient suppression

To prevent a surge on the AC input line, the inrush current of a rectifier module is limited to the full load steady state line current. Modules are also protected from input lightning and transient surges in accordance with ANSI/IEEE C62.41 Category B3 standards.

### 4.1.7 Soft start

A soft start feature is used to eliminate an instantaneous demand on the AC power source. A soft start, sometimes referred to as a “current walk-in”, works by gradually (up to five seconds) ramping up the DC output current limit from zero to the actual or defined customer setting. The rectifier output voltage is ramped from the minimum voltage to the float voltage.

This feature along with Start Delay prevents any instantaneous surge demand on the utility.


## 4.1.8 Start delay

The rectifier modules are equipped with a delay timer to stagger-start a series of modules. When multiple modules and multiple shelves, part of a larger system are used in conjunction with a controller, a start delay prevents all rectifiers from starting at the same time and causing an inrush on the utility. The default start delay is set to 1 second and can be adjusted up to 250 seconds on the Cordex HP controller. The built-in timer delays the switching on of the module by the start delay interval (up to 250 seconds), which is set in the controller.

## 4.1.9 Current limit/short circuit protection

The current limit function determines the maximum output current limit of the rectifier module, regardless of the output voltage or power. The maximum output current is limited to a constant value down to a short circuit condition. Current limiting can be used to mate the rectifier output current ampacity to the needs of the load and parallel battery to minimize excessive battery recharge currents.

The rectifier will sustain a continuous short circuit at the output terminals. The maximum short circuit current will not exceed 62.5A per module.



## 4.1.10 Power limiting

Each rectifier module is designed to limit the power output to the module specification. This enables more current to be supplied at lower output voltages, and allows matching the output power to the demands of constant-power loads often seen in telecom equipment.

This feature can also be used for a faster recharge of flooded batteries paralleled with the load.



### NOTE

**The current limiting feature overrides the power-limiting feature.**

## 4.1.11 High voltage shutdown (HVSD)

This feature protects the load from over-voltages originating in the rectifiers. The offending rectifier module is shut down when a high output voltage condition occurs. The red Alarm (Module Fail) LED will illuminate. The module will restart automatically. However, if more than three over-voltage conditions occur within one minute, the module will latch off and remain shut down until it is reset.

## 4.1.12 Battery eliminator operation

Rectifier modules maintain all specifications (except where indicated) with or without a battery or a DC source attached in parallel to the output. Under these conditions there will be no monitoring or control activity if AC power failure occurs.



### 4.1.13 Mechanical

An integral handle provides a means to both insert and remove the rectifier as well as locking the rectifier in place.

### 4.1.14 Firmware update

The rectifier module should have its operating firmware updated through the Cordex HP controller. Using the latest firmware will ensure the controller has the latest features and that all corrections have been applied.

**NOTE**  
The 3.0kW rectifier requires AC input power to be connected to perform the firmware update.

### 4.1.15 Distribution

#### Bulk

- 23 inch 1RU universal mount P/N 0300057-001 (2.4kW compatible), 0300216-001 (shelf ID support)
- 19 inch 1RU universal mount P/N 0300040-001 (2.4kW compatible), 0300228-001 (shelf ID support)




Figure 2 — 19 inch shelf with bulk distribution busbars

### 4.1.16 Controller

The 3.0kW rectifier shelf is designed to operate with the Cordex HP controller. A controller adds the following capabilities to the rectifiers:

- Local and remote communications and monitoring
- User definable alarms
- Daily logging of events and system statistics
- Load sharing
- Power save

**NOTE**  
The 3.0kW shelf is also designed to operate without a Cordex controller; however, load balancing among the rectifiers won't be as efficient, particularly at lower input voltages. The Cordex HP controller requires version 5.20 (or later) of the software in order to correctly display the system capacity at 120Vac.

### 4.1.17 Internal CAN bus

A CAN bus is used to transmit all alarm and control functions between the controller and rectifier shelves. Two CAN serial ports (modular jacks), are located on the left side of the rectifier shelf as viewed from the front.

The CAN bus can be daisy-chained from shelf to shelf (CAN 1 of one shelf to CAN 2 of another). The last shelf is terminated using a CAN terminator.







Figure 3 — CAN bus connections

## 4.2 Cordex HP 2.4kW rectifier

### 4.2.1 Front panel LEDs

The front panel LEDs indicate the rectifier status summary and patterned response to Locate Module command.

	<p><b>Alarm/Fault</b></p>	<p>The red LED is on during an active Module Fail alarm if the module is unable to source power due to a fault condition. Refer to the relevant controller manual for fault details.</p> <p>The LED flashes (~2Hz) when a minor alarm is detected if the module's output capability has been reduced or a minor failure is detected.</p> <p>The red LED will remain active if the module is receiving power from the DC bus.</p>
	<p><b>DC ON</b></p>	<p>The green LED is on when the rectifier is delivering power to the load. The LED goes out when the rectifier is off. For example, when commanded by the controller.</p>
	<p><b>AC ON</b></p>	<p>The green LED is on when the AC input voltage is qualified and within the operational AC input range and input frequency.</p>

#### LED activity during the Locate Module command from controller

The **Locate Module** command from the controller, causes the LEDs of the target rectifier to flash in a cyclical pattern. This flashing normally lasts 60 seconds.

#### LED activity during power save

When a rectifier is put into power save mode, only the AC ON LED remains illuminated.

### 4.2.2 Rectifier rear panel

Refer to drawings at the end of this manual for shelf power and communications connections (compatible with 2.4kW and 3.0kW rectifiers):

- 0300057-08
- 0300040-08

### 4.2.3 True module fail alarm

The power modules have a “true” fail alarm that provides a true indication of the power module’s ability to source current. When the module’s output current drops below 2.5 percent of the rated output, a low output current condition is detected and the **Module Fail detection circuit** is activated. This circuit momentarily ramps up the output voltage to determine if the module will source current. If no increase in current is detected, the **Module Fail** alarm is activated. The module will test once every 60 seconds for the condition until a current is detected. The output voltage ramping ceases upon detection of current. A minimum 2.5 percent load is required to avoid the **Ramp Test Fail** alarm. This load can be provided with the parallel system battery. Activation of this alarm could indicate a failed module or a failed load.

To avoid nuisance alarms for Cordex rectifier systems without batteries, or with a very light load (below 2.5 percent of the rated output), the ramp test should be disabled. Disable the Ramp Test via the controller menu: **System > DC System > Inventory > Rectifiers > Configuration**.

### 4.2.4 Heat dissipation

Each rectifier module is equipped with a front-mounted, variable-speed fan. The fan speed is determined based on ambient temperature, rectifier temperature and the load. Air flow is front-to-rear with the exhaust air exiting through internal vents at the rear of the unit.

## 4.2.5 Over temperature protection

Blockage or obstruction to the air flow can result in the internal temperature to rise and reduce the output power or even shut down the rectifier. The rectifier will resume normal operation when the temperature reduces to a safe level. Over temperature shut down can also occur when a fan failure has occurred.

## 4.2.6 Wide AC range

The rectifier delivers up to 2400W of power between 187Vac and 310Vac input voltage. The rectifier can deliver up to 1200W between 90Vac and 187Vac.

During start up the rectifier begins to provide power for input voltage >95 Vac and shuts down if the input voltage drops below 85Vac. The THD and power factor will be out of specs for input >277Vac.

## 4.2.7 AC inrush/transient suppression

To prevent a surge on the AC input line, the inrush current of a rectifier module is limited to the full load steady state line current. Modules are also protected from input lightning and transient surges in accordance with ANSI/IEEE C62.41 Category B3 standards.

## 4.2.8 Soft start

A soft start feature is used to eliminate an instantaneous demand on the AC power source. A soft start, sometimes referred to as a “current walk-in”, works by gradually (up to five seconds) ramping up the DC output current limit from zero to the actual or defined customer setting. The rectifier output voltage is ramped from the minimum voltage to the float voltage.

This feature along with Start Delay prevents any instantaneous surge demand from the utility.

## 4.2.9 Start delay

The rectifier modules are equipped with a delay timer to stagger-start a series of modules. When multiple modules and multiple shelves, part of a larger system are used in conjunction with a controller, a start delay prevents all rectifiers from starting at the same time and causing an inrush on the utility. The default start delay is set to 1 second and can be adjusted up to 250 seconds on the Cordex HP controller. The built-in timer delays the switching on of the module by the start delay interval (up to 250 seconds), which is set in the controller.

## 4.2.10 Current limit/short circuit protection

The current limit function determines the maximum output current limit of the rectifier module, regardless of the output voltage or power. The maximum output current is limited to a constant value down to a short circuit condition. Current limiting can be used to mate the rectifier output current ampacity to the needs of the load and parallel battery to minimize excessive battery recharge currents.

The rectifier will sustain a continuous short circuit at the output terminals. The maximum short circuit current will not exceed 50A per module.

## 4.2.11 Power limiting

Each rectifier module is designed to limit the power output to the module specification. This enables more current to be supplied at lower output voltages, and allows matching the output power to the demands of constant-power loads often seen in telecom equipment.

This feature can also be used for a faster recharge of flooded batteries paralleled with the load.



### **NOTE**

---

**The current limiting feature overrides the power-limiting feature.**

### 4.2.12 High voltage shutdown (HVSD)

This feature protects the load from over-voltages originating in the rectifiers. The offending rectifier module is shut down when a high output voltage condition occurs. The red Alarm (Module Fail) LED will illuminate. The module will restart automatically. However, if more than three over-voltage conditions occur within one minute, the module will latch off and remain shut down until it is reset by restarting the rectifier via the controller.

### 4.2.13 Battery eliminator operation

Rectifier modules maintain all specifications (except where indicated) with or without a battery or a DC source attached in parallel to the output. Under these conditions there will be no monitoring or control activity if AC power failure occurs.

### 4.2.14 Distribution

#### Bulk

- 23 inch 1RU universal mount 12,000/15,000W P/N 0300057-001
- 19 inch 1RU universal mount 9,600/12,000W P/N 0300040-001




Figure 4 — 23 inch or 19 inch shelf with bulk distribution busbars

#### Separate feed IO

19 inch 1RU universal mount 4 × 2,400W P/N 0300040-002




Figure 5 — 19 inch shelf with single component distribution

## 4.2.15 Controller

The 2.4kW rectifier shelf is designed to operate with the CXCR/CXCP controller (rack/panel) or the Cordex HP controller. A controller adds the following capabilities to the rectifiers:

- Local and remote communications and monitoring
- User definable alarms
- Daily logging of events and system statistics
- Load sharing
- Power save

### NOTE

**The 2.4 kW shelf is also designed to operate without a Cordex controller; however load balancing among the rectifiers won't be as efficient, particularly at lower input voltages.**

## 4.2.16 Internal CAN bus

A CAN bus is used to transmit all alarm and control functions between the controller and rectifier shelves. Two CAN serial ports (modular jacks), are located on the left side of the rectifier shelf as viewed from the front.

The CAN bus can be daisy-chained from shelf to shelf (CAN 1 of one shelf to CAN 2 of another). The last shelf is terminated using a CAN terminator.




Figure 6 — CAN bus connections








## 5. Inspection

### 5.1 Packing materials

Alpha Technologies is committed to providing products and services that meet our customers' needs and expectations in a sustainable manner, while complying with all relevant regulatory requirements. As such Alpha Technologies strives to follow our quality and environmental objectives from product supply and development through to the packaging for our products.

Rectifiers and batteries are shipped on individual pallets and are packaged according to the manufacturer's guidelines.

Almost all of Alpha's packaging material is from sustainable resources and or is recyclable. See the following table for the material and its environmental codes.

 PAP/PCB	 PET	 PE-LD	 PS	 FE	 ALU	 NW
<b>Cardboard</b>	<b>Polyethylene Terephthalate</b>	<b>Low Density Polyethylene</b>	<b>Polystyrene</b>	<b>Steel</b>	<b>Aluminum</b>	<b>Wood</b>
Packing boxes Caps	Flexible film Packaging	Bubble wrap Shrink wrap Plastic bags	Foam	Strapping on pallets	Strapping on pallets	Pallets Lumber

#### 5.1.1 Returns for service

Save the original shipping container. If the product needs to be returned for service, it should be packaged in its original shipping container. If the original container is unavailable, make sure that the product is packed with at least three inches of shock-absorbing material to prevent shipping damage.

 **NOTE**  
Alpha Technologies is not responsible for damage caused by improper packaging of returned products.

### 5.2 Check for damage

Before unpacking the product, note any damage to the shipping container. Unpack the product and inspect the exterior for damage. If any damage is observed, contact the carrier immediately. Continue the inspection for any internal damage. In the unlikely event of internal damage, inform the carrier and contact Alpha Technologies for advice on the impact of any damage.

### 5.3 General receipt of shipment

The inventory included with your shipment depends on the options you have ordered. The options are clearly marked on the shipping container labels and bill of materials.

#### 5.3.1 Shelves and rectifiers

Consult the packing slip and power system bill of materials to verify that you have the correct number of shelves and rectifiers per your order.

#### 5.3.2 Miscellaneous small parts

Review the packing slip and bill of materials to determine the part number of the "configuration kits" included with your system. Review the bill of materials to verify that all the small parts are included.

## 6. Installation

---

The equipment is suitable for installation in Network Telecommunication Facilities.



### **WARNING!**

**This system is designed to be installed in a restricted access location that is inaccessible to the general public.**

The following procedure is written for qualified personnel to install this product in a clean and dry environment. For the battery installation, refer to the manufacturer's manual.

### 6.1 Installation overview

1. Install shelf in a standard EIA relay rack
2. Connect the shelf chassis ground
3. DC output connections
4. AC input connection
5. Communication cabling (optional)
6. Verify AC and power the recifier shelf
7. Check battery polarity and connections
8. Final tests

### 6.2 Safety precautions

Refer to ["Safety" on page 4](#) before beginning this installation.

### 6.3 Installation tools

Various insulated tools are essential for the installation. Use this list as a guide:

- Battery lifting apparatus if required
- Electric drill with hammer action, ½" capacity
- Various crimping tools and dies to match lugs used in installation
- Load bank of sufficient capacity to load largest rectifier to its current limit
- Digital voltmeter equipped with test leads
- Cable cutters
- Torque wrench: ¼" drive, 0 - 150 in-lb
- Torque wrench: ⅜" drive, 0 - 100 ft-lb
- Insulating canvases as required (1' x 1', 2' x 2', 3' x 3')
- Various insulated hand tools including:
  - Combination wrenches- Ratchet and socket set
  - Various screwdrivers
  - Electricians knife
- Battery safety spill kit required for wet cells
- Wire cutters and strippers (14 AWG to 22 AWG) [2.5 to 0.34 mm<sup>2</sup>]



## 6.4 Assembly and mounting

### 6.4.1 Mounting and grounding a rectifier shelf



#### WARNING!

Ensure that the power is switched off by switching off breakers and removing battery line fuses, turn off battery breakers before attempting work on the wiring. Use a voltmeter to verify the absence of a voltage. Clearly mark the correct polarity of the battery leads before starting work on DC connections.



#### NOTE

Mount the shelf in a clean and dry environment. Allow at least 4.45cm (1.75") of free space in front of the unit for unrestricted cooling airflow. Sufficient free space must be provided at the front and rear of the power system. This is to meet the cooling requirements of the rectifiers and to allow easy access to the power system components.

The 19 inch and 23 inch shelves have been designed for mid mounting in a standard EIA relay rack. Mounting brackets accommodate either 1" or 1-3/4" rack spacing.

Options for flush mounting in a 19 inch or 23 inch rack are also available, but require additional mechanical support at the rear of the unit unless connected to busbars

1. Mount the shelf to the customer-provided rack using at least two #12 – 24 × 1/2" screws in each bracket. Use Phillips type screws and screwdriver to eliminate the possibility of slippage and scratching of the unit's exterior.
2. Connect the shelf chassis ground to the rack. The primary option is using the intended chassis ground location located on the back of the rectifier shelf using a 2-hole lug, 1/4" on 5/8" center. The secondary option is to use rack the shelf is installed into for grounding through the mounting ears. Ensure to be using thread forming screws and star washers to sufficiently remove any paint on non-conductive material and establish a metal to metal contact to ensure a proper electrical bond.




Figure 7 — Protective earth terminal and chassis ground



#### NOTE

In a power system, up to five rectifier shelves may be stacked before a gap must be left for adequate cooling of the rectifiers and shelves.

## 6.5 DC output connections - bulk distribution

### WARNING!

**Do not complete the final live connections to the battery. Leave open and insulate the final connections or remove the battery fuses. Switch off the battery contacts if used.**

The DC output wire must be UL approved XHHW or RHH/RHW (for Canadian users RW90; for European users, must be EN or IEC approved wire). Control and sense wires must be UL approved 1015 (for Canadian users TEW type; for European users, must be EN or IEC approved wire).

If the system is operating in a floating output then no reference or common ground is required to be connected to the power system. If the system is intended to operate in a common bond network than the common output leg must be connected to ground.

Typical locations for connecting reference ground:

1. Battery termination bar
2. Common return bar on the distribution
3. Connection on the back of the 2.4kW / 3.0kW shelf

The 23 inch and 19 inch bulk distribution models have positive and negative output bars.




Figure 8 — Positive and negative output bars on 23 inch and 19 inch bulk distribution models

## 6.5.1 Busbar connection

Multiple shelves can be connected directly to customers' vertical busbar.

1. Remove the bolts and washers at both positive and negative output bars. Bolts are  $\frac{3}{8}$ -16  $\times$  1", and can accommodate up to  $\frac{1}{4}$ " thick busbar.
2. Use fasteners removed from the previous step to secure the vertical busbars to shelf positive and negative output bars. Install all fasteners **finger tight**, then apply 27.12Nm (20 ft-lbf) torque to each bolt.

### NOTE

In a power system, up to five rectifier shelves may be stacked before a gap must be left for adequate cooling of the rectifiers and shelves.




Figure 9 — Connecting output bars to customer's vertical busbars

## 6.5.2 Cable connection

When attaching cables directly to the output bars, use appropriately sized cables terminated with crimp lugs with  $\frac{3}{8}$ " holes on 1" centers.

1. Remove the bolts and washers at both positive and negative output bars. Bolts are  $\frac{3}{8}$ -16  $\times$  1".
2. Use fasteners removed from the previous step to secure the positive and negative cables to the shelf output bars. Install all fasteners **finger tight**.
3. Use a "Tongue and Groove" or similar pliers to hold and stabilize the output bar, torque each bolt to 27.12Nm (20 ft-lbf).




Figure 10 — Connecting output bars directly to cables

## 6.5.3 DC output connections - single component distribution

### 2.4kW rectifier systems only

When attaching cables directly to the output bars, use appropriately sized cables terminated with crimp lugs with M6 bolts on  $\frac{5}{8}$ " centers.

Remove the bolts and washers at both positive and negative output bars. Bolts are M6 x 1.0 x 16. Note: PEM nuts are installed into the bus bar for easier installation.

Use the fasteners removed from the previous step to secure the positive and negative cables to the shelf output bars. Install all fasteners **finger tight**.

Use a "Tongue and Groove" or similar pliers to hold and stabilize the output bar, torque each bolt to 10.85Nm (8 ft-lbf).

The shelf is intended to operate as four independent outputs. Ensure that the controller connected has all load balancing, and power save features disabled.




Figure 11 — 19 inch shelf with single component distribution

### WARNING!

**Do not complete the final live connections to the battery. Leave open and insulate the final connections or remove the battery fuses. Switch off the battery contacts if used.**

## 6.6 AC wiring 23 inch shelf

### 6.6.1 AC feeder protection/sizing

To maximize system reliability it is recommended that, each power module be fed from a dedicated protection feeder breaker located at the AC distribution panel. The feeder breaker can also act as the disconnect device for the connected module. Refer to "[Specifications](#)" for breaker and wire size recommendations.

### 6.6.2 AC input connections



#### CAUTION!

To minimize EMI disturbances, route the AC input wires in flexible or rigid conduit and located as far away as possible from the DC power wires.



#### WARNING!

Use care when removing or replacing the covers for the AC input connections. Never assume that an electrical connection or conductor is not energized.

1. Ensure that all modules are removed from the shelf.
2. At the rear of the shelf, remove screw and flip the cover down (two places) to access the AC input terminal blocks: each terminal pair corresponds to either two rectifiers or a single rectifier.
3. The wire way is designed for two customer-supplied, 3/4" trade size conduit fittings for the AC supplies located on each side of the shelf. Attach the conduit retainers to the wire way holes and route the AC cables through them.
4. Secure the wires to the AC input and AC ground terminals (torque spec. 169.5Ncm or 15in. lbf) and AC ground terminal (395.4Ncm or 35in. lbf). Refer to [Figure 12](#) and customer connection drawing #0300057-08 and #0300216-08 at the end of the manual.
5. Tighten the cable connector to the AC cable (conduit similar).
6. Replace rear covers once all connections have been completed.

NOTE: Rectifier slot numbers 1 to 5 from the left front of the shelf (for reference only).




Figure 12 — AC input and ground for 23 inch shelf

## 6.7 AC wiring 19 inch shelf

For the 19 inch shelf, AC wiring is fed separately to each of the four rectifiers.

### 6.7.1 AC feeder protection/sizing

To maximize system reliability it is recommended that, each power module be fed from a dedicated protection feeder breaker located at the AC distribution panel. The feeder breaker can also act as the disconnect device for the connected module. Refer to "[Specifications](#)" for breaker and wire size recommendations.

### 6.7.2 AC input connections



#### CAUTION!

**To minimize EMI disturbances, route the AC input wires in flexible or rigid conduit and located as far away as possible from the DC power wires.**



#### WARNING!

**Use care when removing or replacing the covers for the AC input connections. Never assume that an electrical connection or conductor is not energized.**

1. Ensure that all rectifier modules are removed from the shelf.
2. At the rear of the shelf, remove the screw and flip the cover down (two places) to access the AC input terminal blocks. Each terminal pair corresponds to an individual rectifier as marked.
3. The wire way is designed for two customer-supplied,  $\frac{3}{4}$ " trade size conduit fittings on each side of the shelf. Attach the conduit retainers to the wire way holes and route the AC cables through them.
4. Secure the wires to the AC input connections (torque spec. 169.5Ncm or 15in. lbf) and AC ground terminal (395.4Ncm or 35in. lbf) as shown in drawing #0300040-08 and #0300228-08 at the end of this manual.
5. Tighten the cable connector to the AC cable (conduit similar).
6. Replace rear covers once all connections have been completed.

## 6.8 Communication cabling (optional)

### 6.8.1 CAN serial ports (rectifier shelf)

Two CAN serial ports (modular jacks), are provided for communications with Cordex controllers and other CAN-enabled equipment. These are located on the left side of the rectifier shelf as viewed from the front.

1. Daisy-chain from shelf to shelf (CAN 1 of one shelf to CAN 2 of another).
2. Insert a CAN terminator (P/N 5450228-001) in the last CAN bus position at the end of the daisy chain.




Figure 13 — CAN bus cabling

### 6.8.2 Shelf ID connection (3.0kW rectifier systems only)

The Shelf ID module can be used for loading individual rectifiers when multiple shelves are used in multiple bays.






Figure 14 — Example of a single bay with two rectifier shelves.





### 6.8.3 Signal wiring connections to L-ADIO board (optional)

For terminal block connections, the recommended wire sizes are 0.823 to 0.129mm<sup>2</sup> (18 AWG to 26 AWG) for the temperature range of 0 to 50 degrees Celsius (32 to 122 degrees Fahrenheit) (as per UL/CSA).



#### CAUTION!

To reduce risk of fire, use only 0.129 mm<sup>2</sup> (26 AWG) or larger wire.

### 6.8.4 Relay outputs

Terminals provide contacts for extending various alarm or control signals. Each relay output can be wired for NO or NC operation during an alarm or control condition.




Figure 15 — Relay connections in the de-energized state

Relays can be programmed to energize or de-energize during an alarm condition (see the [Cordex HP Controller Software Manual](#)). When the controller reset button is pressed or power is lost, all relays de-energize.

### 6.8.5 Digital inputs

The digital input channels are used to monitor various alarm and control signals. All input channels are voltage activated and accept a bipolar (negative or positive) DC signal directly.

#### Connection method

Typical systems use the “reset with Hot and trigger with Ground” connection. The digital input is wired in such a way that the Hot is wired directly into one of the input terminals. For example, the positive input for +24 V systems. The other input terminal is wired to the Ground (common) of the system through a dry contact relay usually located on the equipment requiring monitoring. This method allows the digital input to receive or not receive a Ground signal on an alarm.




Figure 16 — Digital input connection method

## 6.9 System startup

Visually inspect the installation thoroughly.

After completing the system installation and power system wiring, perform the following startup and test procedure to ensure proper operation:

### 6.9.1 Check system connections

1. Make sure that the AC input power is switched off, the batteries are disconnected, and all the power modules are removed from the shelf.
2. Triple-check the polarity of all connections.

### 6.9.2 Verify AC and power the rectifier shelf



#### NOTE

**Do not force a module into position if it does not seat properly. All modules are keyed to ensure that the correct module (voltage/polarity) type is used.**

1. Install one power module into the left most position using the side of the shelf as a guide.
  - a. Place the power module on the shelf bottom and slide the module into the rear connector (inside the shelf).
  - b. Apply pressure on the module handle to engage the rear connector in the shelf receptacle.
  - c. Place the handle in the down position to secure the module to the shelf.
2. Verify that the AC input voltage is correct and switch on the corresponding feeder breaker. The power module **AC ON** LED illuminates after a preset start delay. (See the [Product Features on page 12](#) for a description of the LEDs.)
3. Use the controller, if installed, to test the functionality of various module alarms and controls.

### 6.9.3 Check battery polarity and connections

1. Use a voltmeter to verify that the battery polarity is correct. Ensure that no cells or batteries are reversed.
2. Connect the batteries to the output of the system.
3. Install the remaining power modules.
4. In the adjustments menu of the controller, set the float and equalize voltages to the levels specified by the battery manufacturer.
5. Using the controller, test the functionality of the various module alarms and controls. Perform a load test with the system using a resistive load box.
6. Enable the temperature compensation (temp comp) feature in the batteries menu. Program the settings for slope and breakpoints (upper and lower) according to the specific batteries used.

## 7. Wiring

This chapter provides cabling details and notes on cable sizing for DC applications with respect to the product.



### WARNING!

**Ensure that the power is switched off by switching off rectifiers and removing battery line fuses, turn off battery breakers before attempting work on the wiring. Use a voltmeter to verify the absence of a voltage. Clearly mark the correct polarity of the battery leads before starting work on DC connections.**

### 7.1 Installation notes

Refer to the Installation section for safety precautions and tools required.

### 7.2 Calculating output wire size requirements

Although DC power wiring and cabling in telecommunication applications tend to exceed electrical code requirements, mostly due to the voltage drop requirements, all applicable electrical codes take precedence over the guidelines and procedures in the present chapter, wherever applicable.

Wire size is calculated by first determining the appropriate maximum voltage drop requirement. Use the formula below to calculate the circular mil area (CMA) wire size requirement. Determine the size and number of conductors required to satisfy the CMA requirement.

$$\text{CMA} = (A \times \text{LF} \times K) / \text{AVD}$$

**A = Ultimate drain in amps.**

**LF = Conductor loop feet.**

**K = 11.1 constant factor for commercial (TW type) copper wire.**

**AVD = Allowable voltage drop.**

Check again that the ampacity rating of the cable meets the requirement for the installation application. Consult local electrical codes (for example, NEC or CEC) for guidelines. If required, increase the size of the cable to meet the code.

The following table provides cable size equivalents.

Cable size	Circular mils	Square millimeters	Equivalent metric cable
20 AWG	1020	0.519	1
18 AWG	1624	0.8232	1
16 AWG	2583	1.309	1.5
14 AWG	4107	2.081	2.5
12 AWG	6530	3.309	4
10 AWG	10380	5.261	6
8 AWG	16510	8.368	10
6 AWG	26250	13.30	16
4 AWG	41740	21.15	25
2 AWG	66370	33.63	35
0 AWG (or 1/0)	105600	53.48	50 or 70
00 AWG (or 2/0)	133100	67.42	70
0000 AWG (or 4/0)	211600	107.2	120

Cable size	Circular mils	Square millimeters	Equivalent metric cable
313 MCM (or kcmil)	313600	159	150 or 185
350 MCM (or kcmil)	350000	177.36	185
373 MCM (or kcmil)	373700	189	185 or 240
500 MCM (or kcmil)	500000	253.36	300
535 MCM (or kcmil)	535300	271	300
750 MCM (or kcmil)	750000	380.00	400
777 MCM (or kcmil)	777700	394	400

## 7.2.1 Recommended torque values

Table D lists the recommended torque values for connection to the power system with the following hardware:

- Clear hole connections (nut and bolt)
- PEM studs
- PEM threaded inserts
- Thread formed connections (in copper busbar)

Grade 5 rated hardware is required for these torque values.

¼"	11.93Nm (8.8 ft-lbs)
⅜"	44.06Nm (32.5 ft-lbs)
½"	98.97Nm (73 ft-lbs)

## 7.3 Grounding

This power system is suitable for installation as part of a Common Bonding Network (CBN) and is intended to be used in a DC-C configuration (common DC return).

Connect the isolated power system battery return bus (BRB) to the building master ground bus (MGB), or floor ground bus (FGB) in a larger building. This acts as a system reference and as a low impedance path to the ground for surges, transients, or noise. The MGB or FGB must have a direct low impedance path to the building grounding system.

The cable from the power system to the MGB or FGB must be sized to provide sufficient ampacity to clear the largest fuse or breaker on the power system, excluding the battery protection fuse or circuit breaker. 750 MCM is recommended. This is the minimum requirement. Other factors including the length of the cable and special grounding requirements of the load must also be factored in. The insulated cable must be equipped with two-hole crimp type lugs and must not have any tight bends or kinks.

Power system ampacity	Ground reference conductor size
< 30A	#10
30A to 100A	#6 to #2
100A to 400A	0000
400A to 800A	350 MCM
> 800A	750 MCM

The power system frame must also be connected to the MGB or FGB for personnel safety and to meet many telecom grounding requirements. Each rack must have its own frame or site ground connection.

## 8. Rectifier modes and factory defaults

### 8.1 Rectifier modes

There are two main rectifier modes: output voltage mode and the output current/power mode.

#### 8.1.1 Output voltage modes

Voltage modes are under software control, and can be used to directly adjust the output voltage. The qualification of “under software control” is made because there are processes that occur in the rectifier that can change the output voltage that do not adjust the output voltage directly, for example, if the rectifier has reached the current limit.

Table F lists output voltage modes and a description of when they are active. These modes can be set via the controller.

<b>Output voltage modes</b>	<b>Active when...</b>
Float	Output voltage is set to the float voltage setting.
Equalize	Output voltage is set to the equalize voltage setting.
Battery Test	Output voltage is set to the battery test voltage setting.
Safe	If the rectifier is not connected to a controller, the rectifiers will switch to safe mode (51.4V default) after five minutes.

#### 8.1.2 Output current/power modes

These modes directly affect the output current and power. Table G lists the output current/power modes and a description of when they are active.

<b>Output current modes</b>	<b>Active when...</b>
<b>Temperature foldback mode</b>	Output current and power limit have been reduced because a high temperature has been detected on the heatsink or internal ambient temperature sensor.
<b>AC foldback mode</b>	Output current and power limits have been reduced because the AC input voltage is low. This will reduce the risk of tripping an AC breaker due to increased AC current draw as the AC voltage decreases.
<b>Short circuit foldback mode</b>	Output current limit has been reduced due to a short circuit at the output.
<b>Internal fault foldback mode</b>	Output current limit has been reduced due to an internal fault.
<b>Constant power mode</b>	If the output current exceeds max rated current, the rectifier puts out constant power within a specific voltage range. The rectifier is in constant power mode.
<b>Overload</b>	If the load current increases further, the output voltage and current will reduce. This mode is called fold back mode or Over Load.

## 8.2 Factory ranges and defaults

Table H shows the rectifier settings, ranges, and default values. Changes are made through the controller interface.

<b>Table H — Rectifier factory ranges and defaults</b>		
<b>Setting</b>	<b>Range (minimum to maximum)</b>	<b>Default</b>
<b>Float (FL) Voltage</b>	47.5V to 58V	54V
<b>Equalize (EQ) Voltage</b>	49.8V to 60V	55V
<b>Battery Test (BT) Voltage</b>	44V to 52V	46V
<b>Over Voltage Protection (OVP)*</b>	63V	63V
<b>Current Limit (CL)</b>	20% to 100%	100%
<b>Power Limit (PL)</b>	0% to 100%	100%
<b>Module Start Delay</b>	0s to 250s	1s
<b>System Start Delay</b>	0s to 600s	0s
<b>Low Voltage Alarm (LVA)</b>	42V to 52V	44V
<b>High Voltage Alarm (HVA)</b>	52V to 63V	55.5V
<b>EQ Timeout</b>	1h to 2399h	30h
<b>BT Timeout</b>	1h to 250h	8h
<b>Softstart Ramp-rate</b>	Normal/Fast	Normal
<b>CL/PL Alarm</b>	Enable/Disable	Enable
<b>Remote Shutdown</b>	Enable/Disable	Enable
<b>Ramp Test</b>	Enable/Disable	Enable

\*The OVP cannot be set below the present system/FL/EQ/BT voltage setting or the safe mode voltage of 51.4V.

## 9. Maintenance

Although very little maintenance is required with Alpha systems, routine checks and adjustments are recommended to ensure optimum system performance. Qualified service personnel should do the repairs.

The following table lists a few maintenance procedures for this system. These procedures should be performed at least once a year.



### WARNING!

**Use extreme care when working inside the unit while the system is energized. Do not make contact with live components or parts.**



**Circuit cards, including RAM chips, can be damaged by static electricity. Always wear a grounded wrist strap when handling or installing circuit cards.**

**Ensure redundant modules or batteries are used to eliminate the threat of service interruptions while performing maintenance on the system's alarms and control settings.**

Table I — Sample maintenance log


Procedure	Date completed
Clean ventilation openings.	
Inspect all system connections. Re-torque if necessary.	
Verify alarm/control settings.	
Verify alarm relay operation.	

### 9.1 Replacing a rectifier module via the Cordex HP controller

When a rectifier is permanently removed, the system generates a Rectifier Comms Lost alarm. That alarm is cleared by removing the rectifier from the system inventory.

To remove the rectifier from the system inventory do the following:

1. Remove the defective rectifier from the shelf.
2. To remove a module, flip the handle up and pull the module away from the rear connector and out of the shelf.
3. In the web user interface go to **Power System > Inventory > Rectifiers > Status**.



4. Click the **Unassign** button on the rectifier to be removed and confirm.
5. Place the new rectifier in the shelf.
6. Rectifiers are plug-and-play, but you may still need to map the new rectifier to an AC phase.
7. If not set to auto-assign, go to **Modules > Unassigned Modules** to assign new rectifier.
8. Confirm the assignment.

## 9.2 Replacing a rectifier module via Cordex controller

The rectifier is plug and play. When a rectifier module is added to the system, the controller will detect and update the inventory automatically. Replacing an installed rectifier requires a manual Inventory Update at the controller to clear the removed rectifier from its current list of rectifiers.

1. To remove a module, flip the handle up and pull the module away from the rear connector and out of the shelf.
2. At the controller LCD initiate an Inventory Update as follows (or **Main Menu > Rectifiers > Inventory Update** for the web interface):

Tap the Rectifier icon on the controller home page.

Tap Inventory Update.

A pop-up window appears with a progress bar showing the number of modules acquired during the update.


Inventory Update clears the current list of rectifiers and re-acquires all connected modules.

3. Place the new rectifier module on the shelf bottom. Lift the handle and slide the module into the rear connector (inside the shelf). Apply pressure to the module front panel to engage the rear connector in the shelf receptacle.
4. Flip the handle down to lock the module in place.

## 9.3 Fan replacement

The fan on the individual rectifiers is designed for very high reliability and long life. During year six of the life of the product the manufacturer recommends replacement of the fan assembly.

1. Lift the locking handle and slide the module 10cm (4in.) out of the shelf. Wait ten minutes for the module capacitors to discharge and then slide the rectifier out of the shelf.
2. Remove the two bottom screws that secure the front panel to the module chassis.
3. Push in the two plastic protrusions on top of the rectifier and disengage the front panel and attached fan from the rectifier.
4. Disconnect the fan cables from the module by pulling out the fan cable connector.



5. Discard the old fan assembly and unpack the new replacement assembly.



6. Reconnect the fan cable. Insert the connector into the fan connector in the module. Ensure proper polarity and that the wires stay clear of the fan blade.
7. Slide the front panel into the rectifier body.
8. Ensure the metal tabs of the rectifier body aligned with the screw holes of the front panel.
9. Ensure the plastic tabs of the front panel are protruding through the metal cutouts in the rectifier body.
10. Secure the front cover by hand tightening the bottom screws.

## 10. Troubleshooting

The rectifiers and the shelves are designed for simple installation and reliable, trouble-free operation.

In most cases the rectifiers will recover from minor alarms and faults automatically. However under certain conditions the rectifiers may need remote control. And under very rare cases the rectifier may need a manual reset (unplug and reinsert the rectifier). In the unlikely event of a rectifier failure, it may need replacement.

A 2.4kW | 3.0kW rectifier shelf can accommodate either four or five rectifiers, depending on the model. The rectifiers have three LED indicators that provide information about the system.

When the 2.4kW | 3.0kW shelf system is used in conjunction with a controller, detailed system information and status can be easily obtained. Even more information can be obtained via the web interface using the Ethernet port.

This table provides a quick look up at the LEDs and the corresponding rectifier states.

AC	DC	Alarm/fault	Rectifier state	Possible causes	Solutions
Green	Green	Off	Normal operation		
Green	Off	Off	Unit has no DC output	Unit is in Power Save mode	Unit will automatically resume power delivery power when load is increased or when the Remote restart is enabled.
Off	Off	Off	Unit may not be plugged in or system is off or unit has failed.		Plug in unit completely, check AC and DC wiring.
Off	Off	Red	Unit has shut down due to a fault and may need to be reset. Check controller or web interface to find the fault details.	AC not qualified unit has failed.	
Green	Off	Red	Unit has shut down due to a fault and may need to be reset. Check controller or web interface to find the fault details.	Depending on the fault the unit may or may not recover automatically.	Over temperature fault, will auto recover, plug unit into the shelf.
Green	Off	Blinking Red	Unit has an alarm.		Check the controller front panel or web interface to find out the details of the alarm.
Green	Green	Blinking Red	Unit has an alarm.		Check the controller front panel or web interface to find out the details of the alarm.
Green	Green	Red	Normal operation	Unit is on No LOAD, and no battery is connected. Cordex HP controller will report ramp test fail.	Add load or connect battery, or disable ramp test.

## 11. Acronyms and definitions

AC	Alternating current
ANSI	American National Standards Institute
AWG	American Wire Gauge
BRB	Battery return bus
BTU	British thermal unit
CAN	Controller area network
CBN	Common bonding network
CEC	Canadian Electrical Code
CSA	Canadian Standards Association
CX	Cordex series
CXC	Cordex Controller
CXPS-E3	Cordex Power System Edge
DC	Direct current
EIA	Electronic Industries Alliance
EMC	Electromagnetic compatibility
EMI	Electromagnetic interference
ERM	Electromagnetic Compatibility and Radio Spectrum Matters
ESD	Electrostatic Discharge
FCC	Federal Communications Commission (for the US)
FGB	Floor ground bus
HVSD	High voltage shutdown
IEC	International Electrotechnical Commission
IEEE	Institute of Electrical and Electronics Engineers
IP	Internet Protocol
LVD	Low voltage disconnect
MGB	Master ground bus
MIL	One thousandth of an inch; used in expressing wire cross sectional area
MOV	Metal oxide varistor
MTBF	Mean time between failures
NC	Normally closed
NEC	National Electrical Code (for the US)
NO	Normally open
OSHA	Occupational Safety and Health Administration
OVP	Over voltage protection
RAM	Random access memory
RU	Rack unit (1.75")
TCP/IP	Transmission Control Protocol / Internet Protocol
THD	Total harmonic distortion
UL	Underwriters Laboratories
VRLA	Valve regulated lead acid

## 12. Warranty statement and service information

---

### 12.1 Technical support

**In Canada and the US, call toll free 1.888.462.7487**

**Customers outside Canada and the US, call +1.604.436.5547**

### 12.2 Warranty statement

For full information details review Alpha's online Warranty statement at [www.alpha.ca/support](http://www.alpha.ca/support).

### 12.3 Product warranty

Alpha warrants that for a period of two years from the date of shipment its products shall be free from defects under normal authorized use consistent with the product specifications and Alpha's instructions, the terms of the manual will take precedence.

The warranty provides for repairing, replacing or issuing credit (at Alpha's discretion) for any equipment manufactured by it and returned by the customer to the factory or other authorized location during the warranty period.

There are limitations to this warranty coverage. The warranty does not provide to the customer or other parties any remedies other than the above. It does not provide coverage for any loss of profits, loss of use, costs for removal or installation of defective equipment, damages or consequential damages based upon equipment failure during or after the warranty period. No other obligations are expressed or implied. Warranty also does not cover damage or equipment failure due to causes external to the unit including, but not limited to, environmental conditions, water damage, power surges or any other external influence.

The customer is responsible for all shipping and handling charges. Where products are covered under warranty Alpha will pay the cost of shipping the repaired or replacement unit back to the customer.

### 12.4 Battery warranty

Note that battery warranty terms and conditions vary by battery and by intended use. Contact your Alpha sales representative or the Technical Support team at the above number to understand your entitlements under Battery Warranty.

### 12.5 Warranty claims

Any claim under this Limited Warranty must be made in writing to Alpha **before** sending material back. Alpha will provide Product return instructions upon approval of return request. A Service Repair Order (SRO) or Return Authorization (RA) number will be issued ensuring that your service needs are handled promptly and efficiently.

Claims must be made online at: [www.alpha.ca](http://www.alpha.ca).

### 12.6 Service information

For a list of international service centers, refer to the Alpha website: [www.alpha.ca](http://www.alpha.ca).

# 13. Certification

## About CSA and NRTL

CSA (Canadian Standards Association also known as CSA International) was established in 1919 as an independent testing laboratory in Canada. CSA received its recognition as an NRTL (Nationally Recognized Testing Laboratory) in 1992 from OSHA (Occupational Safety and Health Administration) in the United States of America (Docket No. NRTL-2-92). This was expanded and renewed in 1997, 1999, and 2001. The specific notifications were posted on OSHA's official website as follows:

- Federal Register #: 59:40602 - 40609 [08/09/1994]
- Federal Register #: 64:60240 - 60241 [11/04/1999]
- Federal Register #: 66:35271 - 35278 [07/03/2001]

When these marks appear with the indicator "C and US" or "NRTL/C" it means that the product is certified for both the US and Canadian markets, to the applicable US and Canadian standards. (1)

Alpha rectifier and power system products, bearing the aforementioned CSA marks, are certified to CSA C22.2 No. 60950-01 and UL 60950-01. Alpha UPS products, bearing the aforementioned CSA marks, are certified to CSA C22.2 No. 107.3 and UL 1778.

As part of the reciprocal, US/Canada agreement regarding testing laboratories, the Standards Council of Canada (Canada's national accreditation body) granted Underwriters Laboratories (UL) authority to certify products for sale in Canada. (2)

Only Underwriters Laboratories may grant a licence for the use of this mark, which indicates compliance with both Canadian and US requirements. (3)



## NRTLs capabilities


NRTLs are third party organizations recognized by OSHA, US Department of Labor, under the NRTL program.

The testing and certifications are based on product safety standards developed by US based standards developing organizations and are often issued by the American National Standards Institute (ANSI). (4)


The NRTL determines that a product meets the requirements of an appropriate consensus-based product safety standard either by successfully testing the product itself, or by verifying that a contract laboratory has done so, and the NRTL certifies that the product meets the requirements of the product safety standard. (4)

## Governance of NRTL

The NRTL Program is both national and international in scope with foreign labs permitted.



- (1) [www.csagroup.org](http://www.csagroup.org)
- (2) [www.scc.ca](http://www.scc.ca)
- (3) [www.ulc.ca](http://www.ulc.ca)
- (4) [www.osha.gov](http://www.osha.gov)



NOTE: DAISYCHAIN CAN BUS FROM ONE SHELF TO THE NEXT. INSERT TERMINATOR PIN 5450228-001 IN LAST POSITION.


AC WIREWAY, BOTH SIDES 1.02" Ø HOLE FOR CUSTOMER SUPPLIED 3/4" TRADE SIZE CONDUIT FITTING.

38-16 FOR TERMINAL CONNECTION ON 1" CENTERS

POSITIVE (+) OUTPUT TERMINAL

NEGATIVE (-) OUTPUT TERMINAL


RJ12, CAN 1  
RJ12, CAN 2



DETAIL A  
SCALE: 1:2

L1  
AC FEED FOR RECTIFIER SLOT 4  
L2/N

L1  
AC FEED FOR RECTIFIER SLOT 3  
L2/N





DETAIL B  
SCALE: 1:2


L1  
AC FEED FOR RECTIFIER SLOT 1  
L2/N

L1  
AC FEED FOR RECTIFIER SLOT 2  
L2/N

<b>TITLE: CUSTOMER CONNECTION SHELF, 19" 1RU, 48V-2.4KW</b>	
SIZE: DWG NO. 0300040-08	REV: 1
DWG NO. 0300040-08	REV: 1
SCALE: 1:4	SHEET 1 OF 2



DETAIL A  
SCALE: 1 : 2






DETAIL B  
SCALE: 1 : 2

NOTE: DAISYCHAIN CAN BUS FROM ONE SHELF TO THE NEXT. INSERT TERMINATOR PIN 5450228-001 IN LAST POSITION.

AC WIREWAY, BOTH SIDES 1.02" Ø HOLE FOR CUSTOMER'S SUPPLIED 3/4" TRADE SIZE CONDUIT FITTING.

 an EnerSys company	
TITLE: CUSTOMER CONNECTION, SHELF, 23" W, 48V-2.4KW	
SIZE DWG NO.	REV
B	B
SCALE: 1:8	SHEET 1 OF 1




NOTES:

- THIS SHELF IS FOR ALPHA CXRF-HP 3kW MODULE ONLY

 an Emerson company	
<b>TITLE: CUSTOMER CONNECTION SHELF, 23" 1RU, 48V-3KW</b>	
SIZE	DWG NO. 0300216-08
B	REV A
SCALE	1:8 SHEET 1 OF 1






 an Energyfy company	
<b>TITLE: CUSTOMER CONNECTION SHELF, 19" IRU, 48V-3KW</b>	
SIZE: DWG NO. B	REV A
SCALE: 1:4	SHEET 1 OF 1


DETAIL B  
SCALE: 1 : 2

DETAIL A  
SCALE: 1 : 2


NOTES:  
1. THIS SHELF IS FOR ALPHA CXRF-HP 3KW MODULE ONLY



TITLE		SCHEMATIC	
Bkpl, Shif, CXRF-HP 48V-3.0KW,		19"	
SIZE	DWG NO.	REV	REV
B	0300228-05	A	A




TITLE	SCHEMATIC
REV	B
SIZE	DWG NO.
0300216-05	REV
	A




**alpha** | an EneSys company

TITLE: Shif, 19" 1RU 4Mid SI&O,  
CXRF-HP 48V, 2.4kW

SIZE	DWG NO.	REV
B	0300040-002-05	A



 on EnergySys company	
TITLE: Shelf, 19" 1RU Hor. 4Mdl, CXRF-HP 48V-2.4kW	
SIZE	DWG. NO.
B	0300040-001-05
REV	A
SCALE:	SHEET 1 OF 1



 an EnerSys company	
TITLE: Shelf 23" TRU Hor. 5Mdl, CXRF-HP 48V-2.4KW	
SIZE	REV
B	A
DWG NO. 0300057-001-05	





Alpha Technologies Ltd. | 7700 Riverfront Gate, Burnaby, BC V5J 5M4 CANADA  
Toll Free North America: +1.800.667.8743 | Outside North America +1.604.436.5547 | Technical Support +1.888.462.7487  
For more information visit our website at: [www.alpha.com](http://www.alpha.com)  
© 2021 Alpha Technologies Ltd. All Rights Reserved. Trademarks and logos are the property of Alpha Technologies Ltd. and its affiliates unless otherwise noted. Subject to revisions without prior notice. E. & O.E.

[www.alpha.com](http://www.alpha.com)  
0100037-J0 REV D (05/2021)